

# Operating Instructions

CD CDV LD PLAYER

# CLD-990



**LaserDisc**

NTSC

COMPACT  
**disc**  
DIGITAL AUDIO

**L**  
LASER DISC

- This player does not apply to business use, and CD-ROM/CD graphic discs cannot be played with this player.



Thank you for buying this Pioneer product.

Please read through these operating instructions so you will know how to operate your model properly. After you have finished reading the instructions, put them away in a safe place for future reference.

In some countries or regions, the shape of the power plug and power outlet may sometimes differ from that shown in the explanatory drawings. However, the method of connecting and operating the unit is the same.

**WARNING:** TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.

## IMPORTANT NOTICE

### [For U.S. and Canadian models]

The serial number for this equipment is located on the rear panel. Please write this serial number on your enclosed warranty card and keep it in a secure area. This is for your security.

### [For Canadian model]

**CAUTION:** TO PREVENT ELECTRIC SHOCK DO NOT USE THIS (POLARIZED) PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE.


**ATTENTION:** POUR PREVENIR LES CHOCS ELECTRIQUES NE PAS UTILISER CETTE FICHE POLARISEE AVEC UN PROLONGATEUR, UNE PRISE DE COURANT OU UNE AUTRE SORTIE DE COURANT, SAUF SI LES LAMES PEUVENT ETRE INSEREES A FOND SANS EN LAISSER AUCUNE PARTIE A DECOUVERT.

## LINE VOLTAGE SELECTOR SWITCH

**Only multi-voltage models are provided with this switch. U.S., Canadian, European, U.K., and Australian models are not provided with this switch.**

The line voltage selector switch is located on the rear panel of this player. Before your player is shipped from the factory, the switch is set to the power requirements of the player's destination. Check that it is set properly before plugging the power cord into the outlet. If the voltage is not properly set or if you move to an area where the voltage requirements differ, adjust the selector switch as follows:

Use a medium-sized (flat blade) screwdriver. Insert the tip of the screwdriver into the groove of the selector switch and turn it to set the player to the power voltage of your area.



Set the selector so that arrow points power voltage of your area (Figure shows arrow pointing to 110 volts.)

**PIONEER**  
The Art of Entertainment

# IMPORTANT



The lightning flash with arrowhead, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



**CAUTION:**  
TO PREVENT THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

## SAFETY INSTRUCTIONS

**READ INSTRUCTIONS** — All the safety and operating instructions should be read before the appliance is operated.

**RETAIN INSTRUCTIONS** — The safety and operating instructions should be retained for future reference.

**HEED WARNINGS** — All warnings on the appliance and in the operating instructions should be adhered to.

**FOLLOW INSTRUCTIONS** — All operating and use instructions should be followed.

**CLEANING** — Unplug this video product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

**ATTACHMENTS** — Do not use attachments not recommended by the video product manufacturer as they may cause hazards.

**WATER AND MOISTURE** — Do not use this video product near water — for example, near a bathtub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, etc.

**ACCESSORIES** — Do not place this video product on an unstable cart, stand, tripod, bracket, or table. The video product may fall, causing serious injury to a child or adult, and serious damage to the appliance. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the video product. Any mounting of the appliance should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

**CART** — An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.



**VENTILATION** — Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the video product and to protect it from overheating. These openings must not be blocked or covered. They should never be blocked by placing the video product on a bed, sofa, rug, or other similar surface. This video product should never be placed near or over a radiator or heat register. This video product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

**POWER SOURCES** — This video product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For video products intended to operate from battery power, or other sources, refer to the operating instructions.

### POWER-CORD PROTECTION

Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them. Pay particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.

**POLARIZATION** — This video product is equipped with a polarized alternating current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

**LIGHTNING** — For added protection for this video product receiver during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the video product due to lightning and power-line surges.

**POWER LINES** — An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.

**OVERLOADING** — Do not overload wall outlets and extension cords as this can result in the risk of fire or electric shock.

**OBJECT AND LIQUID ENTRY** — Never push objects of any kind into this video product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the video product.

**SERVICING** — Do not attempt to service this video product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

### DAMAGE REQUIRING SERVICE

Unplug this video product from the wall outlet and refer servicing to qualified service personnel under the following conditions:


- When the power-supply cord or plug is damaged.
- If liquid has been spilled, or objects have fallen into the video product.
- If the video product has been exposed to rain or water.
- If the video product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions. Improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the video product to its normal operation.
- If the video product has been dropped or the cabinet has been damaged.
- When the video product exhibits a distinct change in performance — this indicates a need for service.

**REPLACEMENT PARTS** — When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or having the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

**SAFETY CHECK** — Upon completion of any service or repairs to this video product, ask the service technician to perform safety checks to determine that the video product is in proper operating condition.

**OUTDOOR ANTENNA GROUNDING** — If an outside antenna is connected to the antenna terminal, be sure the antenna system is grounded so as to provide some protection against voltage surges and built-up static charges.

In the U.S.A. section 810 of the National Electrical Code, ANSI/NFPA No. 70-1984, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode. See Fig. A.



NEC — NATIONAL ELECTRICAL CODE

FIG. A

## CONTENTS

<p>Precautions ..... 4</p> <p>Features and Functions ..... 5</p> <p>Accessories ..... 6</p> <p>Remote Control Operations ..... 6</p> <p>Types of Discs that can be played with this Unit ..... 7</p> <p>Care of Discs ..... 9</p> <p>Connections ..... 10</p> <p>Names and Functions ..... 12</p> <p>Display Switching ..... 14</p> <p>To Play an LD, CDV or CD ..... 16</p> <p>To Search for a Particular Time/Frame (Time Number Search/Track Time Search/ABS Time Search/Frame Number Search) ..... 18</p>	<p>To Play Only the Desired Scenes/Tracks (Program Playback) ..... 19</p> <p>Programming Chapters/Tracks to be played back within a Specified Time Period (Compu Program/Auto Program Edit) ..... 20</p> <p>To Play All Chapters/Tracks in a Random Order (Random Playback) ..... 21</p> <p>To Search for a Particular Chapter/Track (Hi-Lite Scan/Intoro Scan) ..... 21</p> <p>Particular Function for CD (Peak Level Search) ..... 21</p> <p>Extra Playback ..... 22</p> <p>To Repeatedly Play a Desired Passage (Repeat Playback) ..... 23</p> <p>Troubleshooting ..... 24</p> <p>Specifications ..... 27</p>
---	--

### INFORMATION TO USER [FOR U.S. MODEL]

This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for a Class B computing device in accordance with the specifications in Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- reorient the receiving antenna
- relocate this equipment with respect to the receiver
- move this equipment away from the receiver
- plug this equipment into a different outlet so that equipment and receiver are on different branch circuits.

If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions. The user may find the following booklet prepared by the Federal Communications Commission helpful:

"How to Identify and Resolve Radio-TV Interference Problems".

This booklet is available from the US Government Printing Office, Washington, D.C., 20402, Stock No. 004-000-00345-4.

*The above instructions apply only to units which will be operated in the United States.*

### CAUTION

- Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.
- The use of optical instruments with this product will increase eye hazard.

### [For Canadian model]

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

- This player may be used with Laser Discs, Compact Discs, and Compact Discs with Video bearing the following symbols:

#### (LASERDISC SYSTEM)/(LaserVision Disc)\*



This is the unified symbol mark of LASERDISC (LaserVision videodisc).

- \* Laser Disc players and discs which bear this symbol and use the same television system, are mutually compatible.

#### (Compact Disc)



#### (\*\*CD VIDEO SYSTEM)



#### (3-inch Compact Disc)



- \*\*A Digital Sound with Multi Audio Disc (CD VIDEO LD) are referred to as CD Video discs. CD Videodiscs are recorded with subcodes, which are the non-audio recordings of TOC data such as track numbers, index numbers, etc. However, there are some discs without these marks.

## PRECAUTIONS

If it becomes necessary to transport or ship this unit in the future, be sure to first remove the disc (if present), retract the disc table to its closed position, turn the power off, and, after the "OFF" indicator stops blinking on the display, disconnect the power cord.

### INSTALLING THE PLAYER

- Place the player on a stable platform next to the television and stereo system to be used with the player.
- When using the player with a stereo system, your speakers should be placed away from your television (or TV monitor).
- Do not place heavy objects such as a television or TV monitor on top of the player.
- Do not place the player on top of your TV set or TV monitor. Also, keep the player away from devices such as cassette decks which are sensitive to magnetic fields.

When FM or AM stations are being received, signal noise may be generated if the player is turned on. Turn off the player when not in use. Also, if there is signal noise when receiving radio stations with an indoor antenna, adjust the position or direction of the antenna.

### INSTALL THE PLAYER IN A WELL VENTILATED PLACE AWAY FROM HEAT AND HUMIDITY

Do not install the player in a location subject to direct sunlight, or near a stove or radiator etc. This could adversely affect the cabinet and internal components. Also avoid installing the player in a humid or dusty location. This could result in a malfunction or accident. Do not install near a cookstove where the player could be affected by smoke, steam, or heat.

### AVOID SOURCES OF HEAT


Do not put the player on sources of heat, such as an amplifier. When installing with audio components on a rack, avoid components that generate heat, by placing the player below such components where there is adequate ventilation and not much dust. Avoid placing the player on surfaces such as shaggy carpets, beds, and sofas which may block ventilation under the player and cause damage.

### CAUTIONS FOR AUTOMATIC LOADING OPERATIONS

Since this player has an automatic loading construction, use the button on the player or the remote control unit for opening and closing of the disc table. To avoid damage, be careful not to apply any force to the moving disc table.

### STRIPE PATTERNS APPEARING ON A TV PROGRAM

Stripe patterns may appear during a TV program if the player unit is turned on, depending on the quality of reception of the TV station. This is neither a malfunction of the television nor the player. If stripes appear while watching the TV, or when watching the TV for long periods of time, turn the player off.



### CONDENSATION

**Moisture will form in the operating section of the player if the player is brought from cool surroundings into a warm room or if the temperature of the room rises suddenly. When this happens, player's performance will be impaired.**

**To prevent this, let the player stand in its new surroundings for about an hour before switching it on, or make sure that the room temperature rises gradually.**

The same, symptoms of condensation may be caused during summer, if the player is exposed to the breeze from an air conditioner. In such cases change the location of the player.

### POWER-CORD CAUTION

Handle the power cord by the plug. Do not pull out the plug by tugging the cord and never touch the power cord when your hands are wet as this could cause a short circuit or electric shock. Do not place the unit, a piece of furniture, etc., on the power cord, or pinch the cord. Never make a knot in the cord or tie it with other cords. The power cords should be routed such that they are not likely to be stepped on. A damaged power cord can cause fire or give you an electrical shock. Check the power cord once in a while. When you find it damaged, ask your nearest PIONEER authorized service center or your dealer for a replacement.

### CLEANING CARE

Use a soft, dry cloth for cleaning. For stubborn dirt, soak the cloth in a weak detergent solution; wring well first and wipe. Use a dry cloth to wipe it dry. Do not use any volatile agents such as benzine or paint thinner, as it may damage the surface of the player.

**Abnormal functioning of this unit may be caused by lightning, static electricity, or other external interference. To restore normal operation, turn the power off and then on again, or unplug the AC power cord and then plug it in again.**

## FEATURES AND FUNCTIONS

### LD (Laser Disc) Playback Functions

#### Program Playback

Up to 24 chapters can be selected from a disc and played in any desired order.

#### Multi-speed Playback (CAV discs only)

The playback speed can be varied in 9 steps in both the forward and reverse directions. Still frame playback and Frame Advance Playback (forward/reverse) are also available.

#### Random Playback (only discs with TOC)

All chapters on a disc can be played in random order.

#### Repeat Playback

Seven repeat modes - Memory Repeat, 1-chapter Repeat, One-side Repeat, Section Repeat, Program Repeat, Random Repeat and Program Random Repeat - are available. (With discs having no TOC, Random Repeat cannot be carried out.)

#### Intro Scan Playback

The beginning of each chapter is played for about 8 seconds.

#### Compu Program Editing/Auto Program Editing (only discs with TOC)

The player automatically selects and programs the chapters which can be played back within a specified time.

### CD (Compact Disc) Playback Functions

#### Program Playback

Up to 24 tracks can be selected from a disc and played in any desired order.

#### Random Playback

All tracks on a disc can be played in random order.

#### Repeat Playback

Seven repeat modes - Memory Repeat, 1-Track Repeat, All-track Repeat, Section Repeat, Program Repeat, Random Repeat and Program Random Repeat - are available.

#### Hi-Lite Scan Playback

Playback starts from a point 1 minute after the beginning of the track, and each track is played for about 8 seconds. Also, Hi-Lite Scan playback can be started from the desired minute and second on each track.

#### Compu Program Editing/Auto Program Editing

The player automatically selects and programs the tracks which can be played back within a specified time.

#### Peak Search function

The player detects the peak level of a CD. This is a convenient function for recording CD play onto the cassette deck.

### CDV (Compact Disc with Video) Playback functions

\* The video part (the section of the disc containing both video and audio) is played first.

#### Video Part:

The same functions available for LD (CLV) playback can be used.

#### Audio Part:

The same functions available for CD playback can be used.

### Other Features

#### Last Memory Function

With this function, if you turn the power switch off during playback of an LD, a playback position slightly ahead of the last frame to be played is stored in memory (last memory). When the power is turned back on, playback begins from the memorized position by pressing PLAY/PAUSE.

#### Auto Loading and Automatic Disc Discrimination Functions

This unit has a built-in motor-driven auto loading mechanism which automatically opens and closes the disc table and makes disc loading easy.

Also, once a disc is placed on the table and the table is retracted into the player, the player automatically detects which type of disc (LD, CD, or CDV) is loaded.

#### 1-Bit D/A Converter

Free of zero-cross distortion, offers smoother and more accurate digital-to-analog conversion, dramatically improving linearity in lower level playback.



#### Compatibility with Many Disc Types and Sizes

In addition to conventional LDs (12-inch, 8-inch), CDs (5-inch), and CDV discs (5-inch), the CLD-990 can play thin-type 8-inch LDs and 3-inch CD singles without an adapter.


## ACCESSORIES

When unpacking the player, first check to make sure that all of the accessories listed below are supplied.


- Remote control unit
- Size "AAA" (IEC R03) dry cell battery x 2



- Video cord (Pin plug ↔ Pin plug)  
Use to connect the player to a color monitor etc.



- Audio cord (Pin plug x 2 ↔ Pin plug x 2)  
Use to connect the player to a stereo amplifier etc.



- Operating instructions
- Warranty card

## REMOTE CONTROL OPERATIONS

### INSERTING BATTERIES INTO THE REMOTE CONTROL UNIT

Open the battery compartment cover on the back of the remote control unit.

Insert size "AAA" (IEC R03) dry cell batteries into the battery compartment in accordance with the indications ( + , - ) inside the compartment.



Close the cover of the battery case.

Incorrect use of batteries may cause leakage or rupture.

Always be sure to follow these guidelines:

- Always insert batteries into the battery compartment correctly matching the positive (+) and negative (-) polarities, as shown by the display inside the compartment.
- Never mix new and used batteries.
- Batteries of the same size may have different voltages, depending on brand. Do not mix different brands of batteries.

When operating the remote control unit, point the unit's infrared signal transmitter at the remote control receiver (REMOTE SENSOR) on the front panel of the player. The remote control unit can be used within a range of about 7 meters (23 feet) from the remote sensor, and within angles of up to about 30 degrees.



### NOTE FOR USING THE REMOTE CONTROL UNIT





- If a plug is connected to the CONTROL IN terminal at the rear of the player, remote control operations cannot be done with the remote control unit aimed at the player's remote control sensor. Aim the remote control unit at the AV control center or the component display's sensor instead.
- If there is any obstacle between the remote control unit and the player, or if the unit is held at too large an angle relative to the front panel of the player, the signal from the remote control unit will fail to reach the remote sensor.
- If the player is operating in the vicinity of other appliances generating infrared rays, or if other remote control devices using infrared rays are used near the player, the player may operate improperly. Conversely, if the player's remote control unit is operated in the vicinity of other appliances which use an infrared remote control device, the other appliance may operate improperly. If this should happen, change the place of installation so that improper operation does not occur.
- If the range of operation of the remote control unit becomes too short, replace the batteries.
- When the unit is not to be used for a long period of time (more than one month), remove the batteries to prevent them from leaking inside the compartment. If leakage occurs, wipe up the liquid inside the compartment and replace the batteries with new ones.
- Do not place books or other objects on the remote control unit, since they might depress the buttons and run down the batteries.



## TYPES OF DISCS THAT CAN BE PLAYED WITH THIS UNIT


This unit is a CD VIDEO SYSTEM (\*1) compatible player which can play CDs, CDV discs, and LDs.

The five disc types listed in the table below can be played with this unit.

\*The marks shown in the left column are printed on the labels and jackets of the corresponding discs.

Mark	Disc	Size	Number of recorded sides	Audio recording system	Video recording system	Other
	CD (Compact Disc) Single	3-inch	One side	Digital (20 minutes max.)		TOC (*2)
	CD (Compact Disc)	5-inch	One side	Digital (74 minutes max.)		TOC
	CDV (CD with Video)	5-inch	One side	Digital (20 minutes max.)	CLV (*3) (5 minutes max.)	TOC *
	CD VIDEO LD (*4)	12-inch, 8-inch	Two sides, one side	Digital/analog	CAV (*5), CLV	TOC **
	LD (LASERDISC/ LaserVision Disc)	12-inch, 8-inch	Two sides, one side	Digital/analog (*6) or analog only	CAV, CLV	

\* There are some discs marked with the  mark instead of the  mark.

\*\* There are some discs without the  mark.

### LD GLOSSARY

#### Chapter number

Chapter numbers are used to indicate the boundaries of the sections on a disc, similar to the "chapters" in a book. If chapter numbers are recorded on a disc, it is so indicated on the jacket of the disc, etc. Chapter numbers can be used to search for desired chapters (Chapter Search).

#### Frame number

Frame numbers are the numbers assigned to each picture frame on a CAV (standard play) disc. Frame numbers can be used to search for desired frames (Frame Search).

#### Time number

Time numbers indicate the time elapsed from the beginning of a CLV (extended play) disc. Time numbers can be used to search for desired scenes (Time Search).

### CDV/CD GLOSSARY

#### Track number

Track numbers indicate the boundaries of the sections, or "tracks", on a disc. Track numbers are assigned consistently throughout the audio part and video part of a CDV disc. Track numbers can be used to search for desired tracks (Track Search).

#### TOC (\*2)

Every CD/CDV-type disc is provided with a section called TOC (Table Of Contents) at the beginning of the disc. The TOC section is just like the table of contents of a book, and contains information on the contents (number of tracks, playing time, etc.) of the disc.

- Some LD discs are also provided with a TOC section.

**Only one disc can be loaded at any one time. Loading a LaserVision Disc, a Compact Disc, a 3" Compact Disc or a Compact Disc with Video on top of one another may result in breakdown, or in scratching of the discs. Please only load one disc at a time.**

**This player is to be used exclusively with the NTSC color system. Please use NTSC LaserVision Disc or NTSC Compact Disc with Video only. PAL and SECAM system discs cannot be used with this player.**

## CD VIDEO SYSTEM (\*1)

The CD VIDEO SYSTEM is the standard name for the "optical video disc with digital audio" system that encompasses both LDs and CDV discs.

The following mark is the standard mark for the CD VIDEO SYSTEM and is found on all players and discs which conform to the CD VIDEO SYSTEM format.

The following systems are included in the CD VIDEO SYSTEM:




- CDV (CD VIDEO CDV) discs
- LaserVision Discs (CD VIDEO LDs) containing digital sound with sub-codes
- Compatible players which can play CDs and CDV discs
- Compatible players which can play CDs, CDV discs, and LDs

### CD VIDEO LDs (\*4)

A CD VIDEO LD is an LD with digital audio which is encoded with sub-codes (data such as TOC and track number data, excluding audio and video signals).

## LDs (LASERDISCS)

With this unit, only play LaserDiscs which bear the following mark.



This mark is the standard mark for LaserDiscs.

Players and discs which bear the LaserVision mark are mutually compatible as long as they conform to the same television system.

Two types of standard LaserDisc are available — standard play (CAV) (\*5) discs and extended play (CLV) (\*3) discs — which differ with respect to their signal recording systems.

### CAV (\*5) DISCS

The jackets and labels of these discs are marked with a "Standard Play Disc CAV" or "Standard Play" indication.

Frames are recorded on these discs at a ratio of one frame per disc revolution, and the discs are played at a fixed rotational speed (CAV = Constant Angular Velocity) of 1,800 rpm. This system is well suited to special playback modes such as still frame playback and multi-speed playback. One side of a CAV disc can have a playback time of up to 30 minutes (for a 12-inch disc), which is equivalent to 54,000 frames. Each frame — from frame 1 to frame 54,000 — is encoded with its own frame number.

\* Playback time varies according to the contents of the disc.

### CLV (\*3) DISCS


The jackets and labels of these discs are marked with a "Extended Play Disc CLV" or "Extended Play" indication.

Signals are recorded on these discs at a constant linear velocity (CLV), and the rotational speed during playback varies from 1,800 rpm for the innermost track to 600 rpm for the outermost track. As a result, one side of a CLV disc can have a playback time of up to 60 minutes (for a 12-inch disc), which is twice as long as a standard play (CAV) disc. CLV discs are encoded with time numbers which correspond to the elapsed play time from the beginning of the disc.

\* Playback time varies according to the contents of the disc.

### LASERVISION DISCS WITH DIGITAL AUDIO (\*6)

The jackets and labels of these discs bear the following mark.



These are LaserDiscs which contain digital audio signals in addition to conventional analog audio signals. This feature allows the high image quality of LaserDiscs to be enjoyed together with the superior quality of digital sound. The digital and analog audio signals are recorded on the disc using different frequency bands.

### LASERVISION MULTI AUDIO DISCS WITH DIGITAL AUDIO

The jackets and labels of these discs bear the following mark.



These are LaserDiscs in which the recorded digital and analog audio signals differ in content. This allows the user to enjoy two different audio soundtracks by switching between the digital and analog sound.

## CDV (COMPACT DISC WITH VIDEO) DISCS


These are compact discs which also contain video signals. Of the total 25-minute playback time of a CDV disc, 20 minutes is encoded with conventional CD digital audio signals (the "audio part"). The remaining 5 minutes is encoded with both video and digital audio signals (the "video part").



## CARE OF DISCS

### How to hold discs


When loading or removing discs, try not to touch their playing surfaces.



### Cleaning

Fingerprints or other dirt on the disc may affect sound and picture quality.

To clean your discs, use a soft clean cloth to wipe them. If necessary, moisten a soft cloth with diluted neutral detergent to remove heavy dirt or fingerprints.




Do not wipe in a circular direction

Gently wipe from the inside toward the outer edge.

Discs may not be cleaned with record cleaning sprays, or static prevention sprays, etc. Also do not use volatile liquids such as benzene, or thinner, etc.

### NEVER PLAY CRACKED OR WARPED DISCS.

- The disc revolves on the player at a high speed when it is played. Never play a cracked, scratched or warped disc. This may damage the player or cause it to malfunction.




### After using discs, store them upright

After playing a disc, always remove it from the player and return it to its jacket. Then store it standing upright away from heat and humidity.

- Store discs carefully. If you store discs at an angle, or stacked on top of each other, discs may become warped even when in their jackets.
- Do not leave discs in locations such as the seat of car, which may become excessively hot.

### If an LD disc is warped...

If an LD disc is warped, put the disc into its protective envelope, and then place it between two flat plates of glass. Then place heavy books on top of the plates so that approximately 4 to 5 kgs (10 lbs) is applied. Leave the disc like this for a day or so. This may correct the warp.



### CAUTION WHEN USING THE DISC


All rights reserved.

Unauthorized public performance, broadcasting or copying is a violation of applicable laws.


# CONNECTIONS

## CONNECTING TV AND STEREO AMPLIFIER


- Connect the VIDEO OUT jack of the player to the video input jack of the monitor television.
- Connect the AUDIO OUT jacks to the stereo amplifier AUX, CD LD, VDP or other jacks, except the PHONO input jacks. The television speakers can also be used by connecting the television audio input jacks and the player AUDIO OUT jacks, however connection to a stereo amplifier is recommended to obtain superior audio playback quality for Compact Discs and LaserDiscs. Do not change the television antenna and VCR connections.




## USING TELEVISION WITH AUDIO AND VIDEO JACKS





## USING STEREO AMPLIFIER WITH VIDEO JACK




## USING PIONEER PROJECTION MONITOR (or COMPONENT DISPLAY)



## USING PIONEER AV CONTROL CENTER WITH THE SR MARK






### PLUG THE POWER CORDS INTO AC OUTLET

Plug the AC power cords of the player, stereo amplifier and TV set into an AC outlet.

When the power cord of this unit is connected to an AC outlet, power is supplied to the unit's internal memory (such as the last memory) even when the POWER switch is OFF. Therefore, be sure to connect the power cord directly to a wall outlet. If the power cord is connected to an outlet such as a switched outlet on an amplifier, the various memory contents will be erased whenever the amplifier's power switch is turned off.

### USING TELEVISION WITHOUT AUDIO AND VIDEO JACKS (WITH OPTIONAL RF MODULATOR JA-RF3L)



### THE SR MARK

System control can be performed when the player is combined with an optional AV control center, which can provide centralized control of Pioneer products with the SR mark.

Connect the VIDEO OUT jack of the player to the video disc video input jack of the AV control center and connect the AUDIO OUT jacks of the player to the audio input jacks of the AV control center.

Connect the CONTROL IN jack of the player to the CONTROL OUT jack of the AV control center using a commercially available cord with mini-plugs.

- For details concerning the connection and operation methods, please refer to the operating instructions for the AV control center.

### NOTE:

When a connecting cord has been connected to the CONTROL IN jack, direct control of the player with the remote control unit is not possible. Operate the player with the remote control unit by aiming it at the AV control center.

1. Detach the VHF antenna cable from the VHF antenna terminal of your TV set, and connect the cable to the VHF IN terminal of the RF modulator JA-RF3L (optional).
2. Connect the VHF OUT terminal of the RF modulator to the VHF antenna terminal of your TV set with the supplied RF cable.
3. Connect the socket (3-pin) of the RF modulator to the VHF ADAPTOR OUTPUT jacks.

### NOTE:

Push the plug in firmly. If the plug is not properly inserted, it may result in snow on the screen or noise.

When the sound from a LaserDisc or Compact Disc is output from a television speaker it becomes monaural sound. (This is the same as stereo television).

### NOTES:

- Stripe patterns may appear when a LaserDisc is played on a television. Move the antenna cable away from the power cord to avoid this.
- Be sure to turn off the power of this player when you watch a TV broadcast.


# NAMES AND FUNCTIONS

A detailed description is provided on the indicated page(s).

Door/Disc table ... p. 16

REMOTE SENSOR ... p. 6

**POWER STANDBY/ON switch**  
Press to turn the power on and off.



Display window

## CHP-TR indicator

Indicates the TR (track) number or CHP (chapter) number.

## REP indicator

Lights during repeat play.

## || PAUSE indicator

Lights when the player is in pause mode.

## ▶ PLAY indicator

Lights during play. Blinks during search.

## EDIT indicator

Lights when editing is performed.

## PEAK indicator

Lights while searching for the peak level.

## FR-TM indicator

Indicates the FR (frame) number or TM (time).

## REMAIN/TOTAL indicator


Indicates the REMAIN TIME (remaining play time) or TOTAL TIME (total play time).

## 1/L, 2/R indicator

Indicates the audio output channel.

## DIGITAL SOUND indicator

Lights when the disc being played has a digital sound signal. With LD discs, this indicator lights when the digital sound signal is selected.



## PGM indicator

Lights during program play.

## HILITE/INTRO indicator



Lights during Hi Lite Scan or Intro Scan mode.

## RANDOM indicator


Lights during random play.

## Visual calendar

When a disc is loaded, all of the chapter/track numbers recorded on the disc light up on the display. If the disc contains more than 15 chapters/tracks, the → indicator lights. During program play, only the programmed chapter/track numbers light. When a disc without a TOC section is played, only the selection number being played lights. When a CDV disc is loaded, the track numbers of the video part light followed by the track numbers of the audio part. After a chapter/track is finished playing, the corresponding number goes out.



# DISPLAY SWITCHING







Information regarding the operations being carried out can be displayed on the screen of the monitor TV. When DISP on the remote control unit is pressed the first time, the screen is displayed.

## With LD discs containing a TOC ...

Each time DISP is pressed, the display changes in the following order: time/frame number (elapsed play time/frame from the beginning of the disc) → Remain Time ALL (remaining play time of the disc) → Total Time (total play time of the disc) → display off.

- With CAV discs, the Disc time ABS (elapsed play time from the beginning of the disc) is displayed after the frame number.



## Other displays

Lights - Flashes	Function	Lights - Flashes	Function
OPEN	Opening of the table	Program	Program mode
CLOSE	Closing of the table	Step-	Chapter/Track program step
STOP	Stop mode	Random	Random play
PLAY	Play mode	Pgm. Rnd	Program random play
PAUSE	Pause mode	Editing	Edit mode
STILL	Frozen picture	Normal	Auto program edit
1/2, 1/4...	Slow-speed play	Compute	Compu program edit
x2, x3	High-speed play	Intro	Intro scan mode
CLV	CLV play	Hilite	HILITE scan mode
Video	Video part search	Peak	Peak search
Audio	Audio part search	Digital	Digital signal setting
Last Memory	Last memory	Analog	Analog signal setting
Repeat Memory	Memory repeat	Stereo	Stereo
Repeat A-B	A-B repeat	1/Lch	Main audio/Left channel
Repeat Side -A (B)	One side repeat	2/Rch	Sub audio/Right channel
Repeat Chapter (Track)	Chapter/track repeat	CX ON	CX noise reduction system ON
Repeat Random	Random repeat play	CX OFF	CX noise reduction system OFF
Repeat Program	Program repeat		

**With LD discs having no TOC...**

Each time DISP is pressed, the display changes in the following order: time/frame number → display off.


**With CDV discs...**

Each time DISP is pressed, the display changes in the following order: elapsed play time of the track being played → Remain Time TRK (remaining play time of the track being played) → Remain Time ALL (remaining play time of the video or audio part being played) → Total Time (total play time from the beginning of the video or audio part being played) → display off.

**With CD discs ...**

Each time DISP is pressed, the display changes in the following order: elapsed play time of the track being played → Disc Time ABS (elapsed play time from the beginning of the disc) → Remain Time TRK (remaining play time of the track being played) → Remain Time ALL (remaining play time of the disc) → Total Time (total play time from the beginning of the disc) → display off.

- These data are also displayed on the display window of the front panel.




**Audio output level meter display:**



During elapsed play time of the track mode of CD playback or CDV (audio part) playback, the audio output level meter will be displayed on the monitor screen.

**NOTE:**


In some cases, the displayed output level may differ from the actual output level, but this is not a malfunction.




# TO PLAY AN LD, CDV OR CD



**1**  
Turn on the power to this unit.




**2**  
Open the disc table.




**3**  
Load a disc


As shown in the following diagram, place the disc on the disc table in the groove corresponding to the size of the disc.  
If the disc is not centered correctly on the disc table, the disc will not be played or the disc or the player may be damaged.  
Always place the disc correctly according to the required disc size on the disc table.



**4**  
Start playback.




**||**  
To pause playback temporarily




The sound and/or video image disappears. Press PLAY/PAUSE ►/|| or PAUSE || again to resume playback from the position where pause mode was entered.

**■**  
To stop playback



When PLAY/PAUSE ►/|| or PLAY ► is next pressed, disc playback starts again from the beginning.

**▲**  
To stop playback and take out the disc



After removing the disc from the disc table, press OPEN/CLOSE ▲, EJECT ■/▲, PLAY/PAUSE ►/|| or PLAY ► to close the table.

**To avoid malfunctions, be especially careful about the following points.**

- Do not place any object other than a disc on the disc table.
- Do not move the player while a disc is playing. This will cause the disc to be scratched.
- Be careful not to catch your finger in the disc table section while the disc table is being retracted into the unit. Also, be careful that children do not put their hands into the inside of the unit while the disc table is open. This may cause injury.


**Precautions concerning disc loading**

- Do not place more than one disc on the disc table. If two discs are placed one on top of the other on the disc table, discs may be scratched and/or malfunction may occur.
- With this unit, playback of all types of discs is carried out without the use of adapters. Therefore, do not use any type of adapter with this unit.





### Chapter (Track) Skip – To search for the beginning of a chapter/track




Press once to return the playback position to the beginning of the chapter/track being played. If the button is pressed more than once before the picture reappears, the beginning of a chapter/track located before the chapter/track being played is searched for and played. The position of the located track corresponds to the number of times the button is pressed.

If this button is pressed once or a number of times, playback is advanced to the beginning of a chapter/track located after the chapter/track being played. The position of the located track corresponds to the number of times the button is pressed.

- Chapter Skip is not possible with discs which are not divided into chapters.



### Manual Search – Search using fast forward or fast reverse



Normally Clear Scan is performed. To perform Low Scan and High Scan, press DISP on the remote control unit to display the screen and then press SCAN button. For about two seconds after the button is pressed, Low Scan is performed, after that, the unit enters High Scan.

**Clear Scan mode:** The image may not be fluctuated in this mode.

**Low Scan mode:** Scan speed becomes about x10 the normal playback speed.

**High Scan mode:** Scan speed becomes about x30 the normal playback speed.

- With CDs or audio part of CDVs, Clear Scan mode cannot be carried out.
- With video part of CDV, High Scan mode cannot be carried out.

- In Clear Scan mode, when digital sound is selected with digital audio discs, sound is heard at low volume level.
- With CDs or audio part of CDVs, sound is heard at low volume level while scanning
- Others: Sound is muted.

#### Notes on CAV:

While scanning, noise may occur on the screen. This is not a malfunction.

#### Notes on CLV:

- While scanning, the color of the image may fade out or the image sometimes fluctuates.
- The scan speed is different between inner tracks and outer tracks.

### Chapter (Track) Search – To search by designating the chapter/track number

#### Example:


To play from the beginning of Chapter/Track 3:

#### <Direct Search>

3

Enter 3 with the digit button.

#### <Normal Search>



#### To search for chapter or track number 10 or above:

Use **[+10]** button.

(Example) To enter 17: **[+10]**, **[7]**

To enter 30: **[+10]**, **[+10]**, **[+10]**, **[0]**

#### If you make a mistake in pressing the digit buttons:

Press CLEAR, and then press the correct button.

#### To identify the present chapter number and frame (or time) number:

The numbers are displayed in the front panel display window.

The information can also be displayed on the monitor TV screen by pressing DISP on the remote control unit.

## TO SEARCH FOR A PARTICULAR TIME/FRAME

### Time Number Search/Track time Search/ABS Time Search/Frame Number Search

#### Time Number Search – Example: To search for the scene located at time number 12 min. 34 sec (CLV)

1. **Press CHP/TM.**  
When the display shows chapter No., press this button again.
2. **Enter 1, 2, 3 and 4 with the digit buttons.**  
If you make a mistake during entry:  
Press CLEAR to reset the time number to "0.00", and press the correct digit buttons again.
3. **Press PLAY/PAUSE ▶/|| or PLAY ▶.**

#### CAUTION

If a disc does not contain information on the digits of seconds, specify the time number only as far as the minute digits.

#### Track Time Search – To search for a time on a specified track (CD/CDV)

1. **Press CHP/TM.**
2. **Press SKIP ◀◀ or ▶▶** so that the desired track number appears in the front panel display window.
3. **Enter the track time (elapsed time from the beginning of the specified track) with the digit buttons (0 - 9).**
4. **Press PLAY/PAUSE ▶/|| or PLAY ▶.**

#### ABS Time Search (CD only) – To search for a point by designating the elapsed time from the beginning of the disc

1. **Press CHP/TM** so that "Ab" appears in the front panel display window. (On the monitor screen, "ABS" appears.)
2. **Enter the elapsed time from the beginning of the disc with the digit buttons (0-9).**
3. **Press PLAY/PAUSE ▶/|| or PLAY ▶.** Playback starts from the specified elapsed time.

#### Frame Number Search (CAV discs only) – To search by designating the frame number

Any desired frame can be searched for by specifying its frame number.

1. **Press CHP/TM.** When the display shows chapter NO., press this button again. "Frame 0" is displayed.
2. **Enter the required frame number with the digit buttons (0 - 9).**
3. **Press PLAY/PAUSE ▶/|| or PLAY ▶.** The designated frame is played as a still frame.

#### NOTES:

- If you make a mistake in pressing the digit buttons, press CLEAR and press the correct digit buttons.
- The +10 button does not function.

#### To exit search mode:

Press CLEAR.


## TO PLAY ONLY THE DESIRED SCENES/TRACKS – Program Playback

Selected chapters (LD) or tracks (CDV/CD) can be played in any desired order (max. 24 chapters or tracks).

- You can view the state of programming on the monitor TV screen.

**Example To play CD tracks No. 9, No. 7, and No. 18 in this order:**


### 1 Press PGM.




### 2 Enter **9**, **7**, **+10**, and **8** with the digit buttons.

If you make a mistake during entry: Press CLEAR and enter the correct number with the digit buttons.

After approx. 1 second



### 3 Press PLAY/PAUSE ▶/||.



### To check the program contents

During program playback or in stop mode, press PGM to display the program contents on the monitor screen. When PGM is pressed again, the program contents disappear.

### To modify the program contents

#### To erase a programmed chapter/track or pause

- Press PGM.
- Press SKIP ◀◀ or ▶▶ to place the cursor (▶) on the left side of the chapter/track or pause to be erased.
- Press CLEAR.
- Press PGM to complete programming. Pressing ▶ also completes programming and starts program playback with the new program contents.

#### To change a programmed chapter/track or pause to a new one

- Press PGM.
  - Press SKIP ◀◀ or ▶▶ to place the cursor (▶) on the left side of the chapter/track or pause to be changed.
  - Enter the new chapter/track number with the digit buttons. Press PAUSE || to enter a pause.
  - Press PGM to complete programming. Pressing ▶ also completes programming and starts program playback with the new program contents.
- Programmed chapter/track being played cannot be erased or changed.
  - Programmed pause being engaged cannot be erased or changed.

#### CAUTION

- If SCAN ▶▶ is held depressed during Program Playback, the playback position will move to another chapter/track, but when ▶▶ is released, the next chapter/track in the program will be played. If ◀◀ is held depressed, the playback position returns to the beginning of the current chapter or track being played, but it will not go beyond it to a previous chapter or track in the program.
- If MULTI SPEED ▶ is pressed during Program Playback, the next track in the program will be played. If MULTI SPEED ◀ is pressed, the playback position returns to the beginning of the current chapter being played, and the player enters normal play mode.

#### Programming a pause:

When recording on a cassette tape, a programmed pause allows you to change the tape side or to record a blank section on the tape which is useful for music search functions, etc. When a program is in pause mode, pressing PAUSE || resumes disc playback, so restart recording before pressing PAUSE ||.

#### To program a pause:

In step 2 of the above procedure, press PAUSE || instead of entering a chapter or track number.

#### NOTE:

- A pause cannot be programmed for step 1, and it cannot be programmed for two consecutive steps.
- A pause can be programmed for the last program step, however, it will not be effective.

#### To stop program play in the middle:

- Press ■ on the front panel of the player or EJECT ■/▲ on the remote control unit.
- Press CLEAR on the remote control unit.

#### To clear the program contents:

- Open the disc table.
- Press CLEAR on the remote control unit in stop mode.

#### Total time display (CD and CDV only):

When programming for CD or CDV, the total time of the programmed tracks is displayed. If the total time exceeds 100 minutes, 100's digit will not be displayed in the display window of the front panel.

- If track No. 33 or more is programmed, the total time will not be displayed.

# PROGRAMMING CHAPTERS/TRACKS TO BE PLAYED BACK WITHIN A SPECIFIED TIME PERIOD – Compu Program/Auto Program Edit

If the total playing time of both sides of the tape is specified, chapters/tracks are automatically programmed for both sides of the tape.

## Compu Program Edit

The player selects the chapters/tracks so that their total playing time becomes the specified playing time as near as possible.

## Auto Program Edit


Chapters/tracks are selected within the designated time, starting from the first track.

### 1 Press EDIT on the front panel.



- When EDIT is pressed during playback, the player enters pause mode.

### 2 Set the total playing time of both sides of the tape in minutes with the digit buttons (0-9).



Press two digit buttons rapidly. For example, to enter 46 minutes, press the [4] button and [6] button sequentially.

## Compu Program Edit

### 3 Press PLAY/PAUSE ►/||.

Program playback starts.



## Auto Program Edit

### 3 Press EDIT again.



### 4 Press PLAY/PAUSE ►/||.

Program playback starts.



When playback of the first program is completed, the player enters pause mode. To play another program, press PLAY PAUSE ►/||.  
When all programs have been played, the player enters stop mode.

#### To clear program contents:

Press CLEAR on the remote control unit.

#### To specify the first track to be programmed:

Only the track to be played first can be specified.

- Press EDIT.
- Select the desired track by pressing SKIP ◀◀ or ▶▶.
- Set the playing time with the digit buttons.

#### If the specified time is too short for any track to be programmed:

Programming cannot be performed.

#### NOTES:

- With discs contained 33 tracks or more, programming may not be correctly performed.
- With Auto Program Edit function, the programmed total playing time is not occasionally close to the specified time compared with Compu Program Edit.
- With LD discs, chapter No. 0 will not be programmed.
- When chapter No. 1 is programmed, the programmed total playing time may slightly differ from the actual calculation. This is not a malfunction.

## TO PLAY ALL CHAPTERS/TRACKS IN A RANDOM ORDER

### - Random Playback

Random Playback allows all chapters/tracks in random order. Press RANDOM PLAY on the front panel.



#### NOTE:

With Random Playback, chapter No. 0 will not be played.

#### To go to the next chapter/track during Random Playback:



Press ►►. (The previous chapter/track cannot be played by pressing ◀◀.)

#### To stop Random Playback:

Press CLEAR on the remote control unit. After CLEAR is pressed, playback will continue in the order in which the chapters/tracks are recorded on the disc.

#### Display during Random Play (CD)

To display the music calendar, press DISP on the remote control unit so that the display shows time display.



#### Random Playback with CDV discs:

Tracks in the video and audio part are played in a random order.

#### Program Random Playback:

To play the programmed chapters/tracks in random order, press RANDOM PLAY during program playback.

## LD/CDV/CD

## TO SEARCH FOR A PARTICULAR CHAPTER/TRACK

### Hi-Lite Scan/Intro Scan



#### Hi-Lite scan (CD or audio part of CDV)

When HILITE/INTRO SCAN on the front panel is pressed during stop mode, playback starts from a point 1 minute after the beginning of the track, and each track is played for about 8 seconds. The HILITE/INTRO indicator is lit on the display during Hi-Lite Scan mode. (On the screen, "Hilite" is displayed.)

#### Intro Scan (LD or video part of CDV)

When HILITE/INTRO SCAN on the front panel is pressed, the beginning of each chapter is played for about 8 seconds. The HILITE/INTRO indicator is lit during Intro Scan mode.

## CD/CDV (Audio part)

## PARTICULAR FUNCTION FOR CD - Peak Level Search

With this function, the peak level of CD or CDV (audio part) can easily be searched for. This is convenient for adjusting the proper recording level.

To search for the peak level of the entire disc: Press PEAK SEARCH on the front panel.



The player scans the entire disc and searches for the peak level. It takes for about 1 minute and 20 seconds with 60-minute disc. While searching, the PEAK indicator is lit on the display.


To search for the peak level of the programmed tracks: Program the desired tracks beforehand (page 19) and press PEAK SEARCH. The player scans all of the programmed tracks and searches for the peak level between them.

#### NOTES:

- The player sometimes detects the different peak level even when the peak search function is carried out on one disc.
- With some discs, the player cannot detect the proper peak level. This is not a malfunction.



## EXTRA PLAYBACK (REMOTE CONTROL UNIT OPERATION)

### Still frame and Frame-by-Frame advance function



During playback if STEP on the remote control unit is pressed, the picture will be frozen. At this point, the disc can be played one frame at a time in either the forward or reverse direction by pressing one of these buttons. The sound is muted during still frame or frame advance operation. To return to normal playback operation, press PLAY ►.

### To vary the playback direction or speed



During playback, the playback direction can be changed with MULTI-SPEED. 1/4 the normal playback speed is set automatically.

With + and - buttons, the playback speed can be changed from x 3 to 1/90 the normal playback speed. Sound is muted during Multi-speed playback operation. To return to normal playback operation, press PLAY ►.

- The selected speed is displayed by pressing DISP on the remote control unit.

Speed display	Speed
x3	3 times the normal playback speed.
x2	Twice the normal playback speed.
x1	Normal playback speed.
1/2	1/2 the normal playback speed.
1/4	1/4 the normal playback speed.
1/8	1/8 the normal playback speed.
1/16	1/16 the normal playback speed.
1/30	1/30 the normal playback speed.
1/90	1/90 the normal playback speed.

**If playback automatically switches to still frame display mode.**  
If a disc containing special signals called "picture stop codes" is played at x1, 1/2, 1/4, 1/8, 1/16, 1/30 or 1/90 speed, playback pauses automatically whenever the unit encounters a frame where a picture stop code is encoded, and the still picture of that frame is displayed on the monitor screen. To move from that position, press PLAY ►.

### Selecting the sound mode

To listen to only one channel of a stereo disc, or to select the audio on a sound multiplex disc

During playback

	Played audio		Display on display window
	Stereo disc	Sound multiplex disc	
Stereo	Audio 1/L (Left) Audio 2/R (Right)	1/L 2/R	
Left	Audio 1/L (Left)	1/L	
Right	Audio 2/R (Right)	2/R	
	Return to start		

To listen to the analog audio of an LD digital audio disc:

During playback




	Played audio	Display on display window
D/A/CX	Digital	DIGITAL SOUND
D/A/CX	Analog	_____
	Return to start	


### Examples of the various types of audio recorded on Multi Audio discs

Disc	Audio	Analog audio	Digital audio
Movies, animations, etc.		Audio of the main program	Soundtrack
Dual music		Music 1	Music 2
Various types of digital audio karaoke		1/L Karaoke (monaural) 2/R Assisting vocals	Stereo karaoke
Stereo bilingual		Native language	Foreign language 1

Disc	Audio	Analog audio	Digital audio
Trilingual		Native language	1/L Foreign language 1 2/R Foreign language 2
Quadlingual		1/L Native language 2/R Foreign language 1	1/L Foreign language 2 2/R Foreign language 3


### Discs marked with the mark

Discs marked  are recorded with the CX noise reduction system for powerful audio reproduction with little noise. (Analog audio only) However, some discs marked  are not encoded with the signals necessary to instruct the unit to automatically switch on the CX system. If sound is noisy or undulate when a disc with a  mark is played, press D/A/CX button on the remote control unit.

-  is a trademark of CBS inc. This player meets the CX EXPANDING SPECIFICATION.

## TO REPEATEDLY PLAY A DESIRED PASSAGE – Repeat Playback


### Memory Repeat – To specify a point to return to later



Press REPEAT A on the remote control unit at the point you want to see or listen to again (point A).

When you wish to return to point A, press PLAY on the remote control unit.


### A-B Repeat – To repeat a specified section



Press REPEAT A on the remote control unit at the start point of the section to be repeated.


Press REPEAT B on the remote control unit at the end point of the section to be repeated. Playback returns to the beginning of the section and the section is repeated continuously.

### Chapter/Track Repeat – To repeat the current chapter or track



Press REPEAT B on the remote control unit while the chapter/track to be repeated is playing. When the end of the chapter/track is reached, the player returns to the beginning of the chapter/track and the chapter/track is played back repeatedly.

### One Side Repeat – To repeat an entire side of a disc




Press REPEAT B twice. When playback reaches the end of the playback side, the player returns to the beginning of the disc and the same side is played back repeatedly.

### Program Repeat – To repeat a program

With the program repeat function, you can repeatedly play programmed chapters or tracks in their programmed order.


- See page 19 for details on programming.



Press REPEAT B while the program is being played.

### Random Repeat – To repeat a random play


With the random repeat function, you can repeatedly play the chapters or tracks in random order.



Press REPEAT B during random playback.

### Program Random Repeat – To repeat a program random play

With the program random repeat function, you can repeatedly play the programmed chapters or tracks in random order.



Press REPEAT B during program random playback.

#### To exit repeat mode:

Press CLEAR on the remote control unit. Repeat mode is canceled and normal playback continues from the current point.

#### To specify a different point in Memory Repeat mode:

Press REPEAT A at the new point. The previously memorized point is erased and replaced with the new point.

#### Memory Repeat and A-B Repeat with CDV discs:

These repeat functions can only be carried out within the video part or within the audio part, and cannot be carried out between the two parts.

#### With LDs which have no chapter numbers:

Chapter repeat cannot be carried out. With such discs, playback enters One Side repeat mode by pressing REPEAT B.

## TROUBLESHOOTING


Incorrect operations are often for trouble and malfunctions. If you think that there is something wrong with this component, check the points below. Sometimes the trouble may lie in another component. Inspect the other components and electrical appliances being used. If the trouble cannot be rectified even after executing the checks listed below, ask your nearest PIONEER authorized service center or your dealer to carry out repair work.

SYMPTOM	CAUSE	REMEDY
1. Disc table is not ejected when OPEN/CLOSE is pressed.	<ul style="list-style-type: none"> <li>● Power cord is not properly plugged into AC wall socket.</li> <li>● Power switch is not turned on.</li> </ul>	<ul style="list-style-type: none"> <li>● Plug in power cord.</li> <li>● Turn on power switch.</li> </ul>
2. Disc table comes out.	<ul style="list-style-type: none"> <li>● Disc is dirty.</li> <li>● The disc is not properly set on the disc table.</li> <li>● Moisture has condensed on parts in the player.</li> <li>● Disc is warped.</li> </ul>	<ul style="list-style-type: none"> <li>● Clean disc.</li> <li>● Set the disc properly.</li> <li>● Remove disc and let player stand for 1 to 2 hours until it is dry.</li> <li>● Try to alleviate the warp. (Refer to Symptom 7, remedy column.)</li> </ul>
3. Remote control does not work.	<ul style="list-style-type: none"> <li>● The CONTROL IN jack on the rear panel is connected to pioneer projection monitor or AV control center.</li> <li>● Batteries are weak.</li> <li>● There is an obstacle between the player and the remote control unit.</li> <li>● Remote control unit is not in a good location for transmission.</li> </ul>	<ul style="list-style-type: none"> <li>● Aim the remote control unit at the projection monitor or AV control center.</li> <li>● Replace batteries.</li> <li>● Remove the obstacle or shift the remote control position.</li> <li>● Operate the remote control unit in front of the player.</li> </ul>
4. Operation of the remote control unit causes the TV to operate improperly.	<ul style="list-style-type: none"> <li>● Some TV sets have remote control functions that operate improperly in response to the remote control unit of the player.</li> </ul>	<ul style="list-style-type: none"> <li>● Move the TV and the player further apart, or cover the remote sensor of the TV during disc playback.</li> </ul>



## TROUBLESHOOTING

### WHEN A LASERVISION DISC IS BEING PLAYED

SYMPTOM	CAUSE	REMEDY
5. Disc is rotating but there is no picture.	<ul style="list-style-type: none"> <li>● The TV set is not turned on.</li> <li>● Wrong connections from player to TV.</li> </ul>	<ul style="list-style-type: none"> <li>● Turn on TV.</li> <li>● Make correct connections.</li> </ul>
6. Picture continuously moves vertically.	<ul style="list-style-type: none"> <li>● The TV vertical hold control is not adjusted properly.</li> </ul>	<ul style="list-style-type: none"> <li>● Adjust vertical-hold control on TV.</li> </ul>
7. Particular disc does not playback properly. The playback stops in the middle of the disc program.	<ul style="list-style-type: none"> <li>● The playing surface of the disc is dirty.</li> <li>● The disc is warped.</li> </ul>	<ul style="list-style-type: none"> <li>● Use a soft cloth and lightly wipe off the dirt from the surface of the disc. If necessary, moisten a cloth with diluted neutral detergent to remove heavy dirt or fingerprints.</li> <li>● LD discs only Put the disc into the protective envelope, then place it on a flat desk top. Subsequently, place a flat board e.g. glass plate on the disc, and load it with about 4 ~ 5 kgs (about 10 lbs). If it is left in this state for one day, sometimes the warp will alleviated.</li> </ul> <div style="text-align: center; margin-top: 10px;">  <p style="font-size: small; margin: 0;">Heavy books about 4 ~ 5 Kgs (10 lbs)</p> <p style="font-size: small; margin: 0;">Glass plate</p> <p style="font-size: small; margin: 0;">LD disc</p> <p style="font-size: small; margin: 0;">Glass plate</p> <p style="font-size: small; margin: 0;">Protective envelope</p> </div>
8. Sound is unnatural or distorted.	<ul style="list-style-type: none"> <li>● CX system is turned ON for disc which has no  mark.</li> </ul>	<ul style="list-style-type: none"> <li>● Press D/A/CX to turn CX system OFF.</li> </ul>
9. No sound output during playback.	<ul style="list-style-type: none"> <li>● MULTI-SPEED or STILL/STEP playback is being performed. Sound is output only during the normal play mode. The audio signals are not output during other playback modes.</li> </ul>	<ul style="list-style-type: none"> <li>● Press PLAY or PLAY/PAUSE to set the player to normal play mode.</li> </ul>
10. During STILL playback, a part of the screen image shakes.	<hr style="width: 20%; margin: 0 auto;"/>	<ul style="list-style-type: none"> <li>● Even if the disc is a standard play disc, there may be some cases in which a fully still image cannot be obtained, but this does not mean that the player or the disc is defective.</li> </ul>
11. CHAPTER SKIP, CHAPTER PROGRAM PLAY and CHAPTER NUMBER SEARCH cannot be performed.	<ul style="list-style-type: none"> <li>● Disc in which no chapter numbers are recorded is loaded.</li> </ul>	<ul style="list-style-type: none"> <li>● Press DISP to check if chapter number is displayed.</li> </ul>
12. Certain discs take too long to search for or do not search for.	<ul style="list-style-type: none"> <li>● It takes time to read the recorded code, depending on the disc.</li> </ul>	<ul style="list-style-type: none"> <li>● Press CLEAR and picture will appear. (At this point, a slightly different scene from that which has been searched for may appear.)</li> </ul>

## TROUBLESHOOTING

SYMPTOM	CAUSE	REMEDY
13. Certain discs take too long to start or do not start.	<ul style="list-style-type: none"> <li>There are errors when the disc code is read (There is no damage to the unit).</li> </ul>	<ul style="list-style-type: none"> <li>Press ■ or ■/▲ and stop the playback. Press the ► or ►/   and start the playback again. (Repeat this operation a few times.)</li> </ul>
14. The player takes too long to find point A during A-B (INTERVAL) REPEAT operation.	<ul style="list-style-type: none"> <li>Same as item 12 above.</li> </ul>	<ul style="list-style-type: none"> <li>Same as item 12 above. (The repeat mode is cancelled).</li> </ul>
15. Picture other than instructed is searched in TIME NUMBER SEARCH mode.	<ul style="list-style-type: none"> <li>Method of inputting numerals in the TIME NUMBER SEARCH mode differs, depending on whether time number is recorded on disc in hours and minutes or minutes and seconds, as shown below; [e.g.] 12-minute search</li> <li>Disc in which time number is recorded in hours and minutes</li> </ul> <div style="text-align: center;"> </div> <ul style="list-style-type: none"> <li>Disc in which time number is recorded in minutes and seconds</li> </ul> <div style="text-align: center;"> </div>	

### WHEN PLAYING BACK A COMPACT DISC

SYMPTOM	CAUSE	REMEDY
16. Player stops immediately after playback is started.	<ul style="list-style-type: none"> <li>Disc is loaded upside down (CD, CDV, onesided LD discs).</li> <li>The playing surface of the discs is dirty.</li> <li>Disc is not properly set on the disc table.</li> </ul>	<ul style="list-style-type: none"> <li>Load the disc correctly with the label side upward.</li> <li>Use a soft cloth and lightly wipe off the dirt from the surface of the disc. If necessary, moisten a cloth with diluted neutral detergent to remove heavy dirt or fingerprint.</li> <li>Set the disc properly.</li> </ul>
17. No sound output	<ul style="list-style-type: none"> <li>The stereo amplifier is not correctly connected.</li> <li>You are not operating the stereo amplifier correctly.</li> <li>The connection terminals and/or the plugs of the connection cords are dirty.</li> <li>The plugs of the connection cords are disconnected, or are not fully pushed in.</li> <li>The player is in pause mode.</li> </ul>	<ul style="list-style-type: none"> <li>Connect the amplifier correctly.</li> <li>Refer to the operating instructions for the amplifier, and operate the amplifier correctly.</li> <li>Clean the plugs and terminals and connect again.</li> <li>Make sure that connections are made correctly.</li> <li>Press ► or ►/   and restore the player to play mode.</li> </ul>
18. Sound is distorted.	<ul style="list-style-type: none"> <li>The audio output jacks are connected to the PHONO jacks.</li> <li>The connection terminals and/or the plugs of the connection cords are dirty.</li> <li>The plugs of the connection cords are not fully pushed in.</li> </ul>	<ul style="list-style-type: none"> <li>Connect to the AUX, CD, VDP or LD jacks.</li> <li>Clean the plugs and terminals and connect again.</li> <li>Push the plug in firmly.</li> </ul>

*Abnormal functioning of this unit may be caused by lightning, static electricity, or other external interference. To restore normal operation, turn the power off and then on again, or unplug the AC power cord and then plug it in again.*




## SPECIFICATIONS

### 7. Functions

	Function	Standard play Disc (CAV)	Extended play Disc (CLV)	Compact Disc with Video	Compact Disc
Basic Functions	Single-side play	YES	YES	YES	YES
	Pause	YES	YES	YES	YES
	Stop	YES	YES	YES	YES
Search	Fast forward (forward and reverse)	YES	YES	YES	YES
	Chapter/Track skip	YES	YES	YES	YES
	Direct chapter/Track number search	YES	YES	YES	YES
	Frame number search	YES	NO	NO	NO
	Time number search	NO	YES	YES	YES
	Absolute time search	NO	NO	NO	YES
Program	Chapter/Track program play	YES	YES	YES	YES
	Program correction	YES	YES	YES	YES
Repeat	Repeat between 2 points	YES	YES	YES	YES
	Memory repeat	YES	YES	YES	YES
	Chapter/Track repeat	YES	YES	YES	YES
	One-side repeat	YES	YES	YES	YES
	Program repeat	YES	YES	YES	YES
	Random repeat	YES*1	YES*1	YES	YES
	Program random repeat	YES	YES	YES	YES
Trick play	Still/Step	YES	NO	NO	NO
	Multi-speed (Forward/reverse 9-level variable)	YES	NO	NO	NO
Time display	Elapsed time display	NO	YES	YES	YES
	Absolute time display	YES*1	NO	NO	YES
	Remaining track time display	NO	NO	YES	YES
	Remaining total time display	YES*1	YES*1	YES	YES
	Total number of selections, total time display	YES*1	YES*1	YES	YES
Others	Hi-Lite scan	NO	NO	YES*4	YES
	Intro scan	YES	YES	YES*5	NO
	CX system ON/OFF	YES*2	YES*2	NO	NO
	AUTO DIGITAL/ANALOG switch	YES*3	YES*3	NO	NO
	Audio channel selection (Stereo, 1/L, 2/R)	YES	YES	YES	YES

\*1 Only discs with TOC

\*2 Valid for analog sound playing a disc with the  mark.

\*3 Can only be used with discs with digital sound tracks.

\*4 Audio part only

\*5 Video part only

**NOTE:**

*The specifications and design of this product are subject to change without notice, due to improvement.*

### PLAYER FUNCTIONS

- Display, Visual Calendar Display
- Intro Scan, Hi-Lite Scan, Peak Search, Random Playback, Program Random Playback and Compu Program/Auto Program Edit
- Digital Sound for LaserVision Discs
- Last Memory

Published by Pioneer Electronic Corporation.  
Copyright © 1991 Pioneer Electronic Corporation.  
All rights reserved.

**LaserDisc** is a trademark of Pioneer Electronic Corporation.

**PIONEER ELECTRONIC CORPORATION** 4-1, Meguro 1-Chome, Meguro-ku, Tokyo 153, Japan

**PIONEER ELECTRONICS [USA] INC.** 2265 East 220th Street, Long Beach, California 90810, U.S.A.

P.O. BOX 1720, Long Beach, California 90801, U.S.A.

**PIONEER ELECTRONICS OF CANADA, INC.** 505 Cochrane Drive, Markham, Ontario L3R 8E3, Canada

**PIONEER ELECTRONIC [EUROPE] N.V.** Keetberglaan 1, 9120 Beveren, Belgium, TEL: 03/750.05.11

**PIONEER ELECTRONICS AUSTRALIA PTY. LTD.** 178-184 Boundary Road, Braeside, Victoria 3195, Australia, TEL: [03] 580-9911